NURF TC 1.0mL

iKrusher

FILLING INSTRUCTIONS

01



- Unpackage the product, make sure you have both the mouthpiece and the cartridge ready.
- Do not remove the silicone cap.
- Place the cartridge vertically upright on a tray.

02



- Pre-heat the oil to ⩽ 122 degrees Fahrenheit.
- Fill the oil with a syringe or a machine, the recommended needle size is Gauge 16 (or ⩽1.8mm).
- Fill the oil according to the tank capacity, through only one of the filling holes on top of the cartridge, avoiding the center post.
- When using a needle, insert it to a depth of 2/3 of the oil tank and do not touch the bottom.

03



***Press machine recommended**

- Cap the mouthpiece onto the cartridge, make sure it is vertical to the tank and forced evenly.
- Do this within 1.5 minutes after filling the oil. For thinner consistencies, please cap it sooner to prevent leaking.

After Filling

(*If you are using Live Resin or Live Rosin, please skip this step.)

- After filling and capping, invert the cartridge upside down to ensure the oil cools away from the coil. This is to prevent leakage.
- Once the cartridge has been flipped upside down for 30 minutes, flip it right side up for another 30 minutes. This allows the oil to fully saturate the coil and to prevent potential dry hits.
- Store the final product in a dry, cool place that avoids direct sunlight. Storage temperatures should be between 68-77 degrees Fahrenheit.



Additional Info

- Once it is filled, you will notice a difference in volume as the ceramic coil absorbs the oil. This will create a headspace in the oil tank, with a potential reduction of up to 10%.
- for Consumers Only: After opening,please finish this product within 2 weeks for the best experience.

NURF TC 2.0mL

iKrusher

FILLING INSTRUCTIONS

01



- Unpackage the product, make sure you have both the mouthpiece and the cartridge ready.
- Do not remove the silicone cap.
- Place the cartridge vertically upright on a tray.

02



- Pre-heat the oil to ⩽ 122 degrees Fahrenheit.
- Fill the oil with a syringe or a machine, the recommended needle size is Gauge 16 (or ⩽1.8mm).
- Fill the oil according to the tank capacity, through only one of the filling holes on top of the cartridge, avoiding the center post.
- When using a needle, insert it to a depth of 2/3 of the oil tank and do not touch the bottom.

03



***Press machine recommended**

- Cap the mouthpiece onto the cartridge, make sure it is vertical to the tank and forced evenly.
- Do this within 1.5 minutes after filling the oil. For thinner consistencies, please cap it sooner to prevent leaking.

After Filling

(*If you are using Live Resin or Live Rosin, please skip this step.)

- After filling and capping, invert the cartridge upside down to ensure the oil cools away from the coil. This is to prevent leakage.
- Once the cartridge has been flipped upside down for 30 minutes, flip it right side up for another 30 minutes. This allows the oil to fully saturate the coil and to prevent potential dry hits.
- Store the final product in a dry, cool place that avoids direct sunlight. Storage temperatures should be between 68-77 degrees Fahrenheit.



Additional Info

- Once it is filled, you will notice a difference in volume as the ceramic coil absorbs the oil. This will create a headspace in the oil tank, with a potential reduction of up to 10%.
- for Consumers Only: After opening,please finish this product within 2 weeks for the best experience.